

NOTES:

THIS SEQUENCE CARD HAS BEEN FACTORY SET TO OPERATE IN ACCORDANCE WITH THE MODEL NUMBER INDICATED ON THE CLEAR PLASTIC HANDLE.

CHANGING THE PROGRAMMING JUMPER CONFIGURATION FROM THEIR FACTORY SETTINGS WILL ADVERSELY AFFECT THE OPERATION OF THE CARD.

ONLY THOSE JUMPERS INDICATED IN THE DIAGRAM ABOVE ARE DESIGNED FOR FIELD SELECTION OF CUSTOMER OPTIONS PER TABLE "A" BELOW.

TABLE A						
SEQUENCE OR OPTION	SEQUENCES AF1, AF5, or AF12 (ONLY!) USE JUMPER:	RELAY OUTPUT OPTIONS (1, 3, 4, 5, OR 6) AE, BE or CE USE JUMPER:	ALL SEQUENCES USE JUMPER:			
SET JUMPER	J33 TO SET LOCKIN (LI) OR NON-LOCKIN (NLI)	J31 TO SET K1 FOR ENERGIZED IN NORMAL (EN) OR DE-ENERGIZED IN NORMAL (DE)	J13 TO SET FIELD CONTACT FOR: NORMALLY OPEN (NO) OR NORMALLY CLOSED (NC)			
EXAMPLE OF JUMPER SETTING	J33 NLI LI LI SET FOR SET FOR LOCKIN NON-LOCKIN	SET FOR SET FOR ENERGIZED IN NORMAL NORMAL	SET FOR SET FOR NORMALLY OPEN CLOSED			

 \gg FOR CARDS WITHOUT A RELAY OUTPUT OPTION INSTALLED, JUMPER J31 WILL NOT BE PRESENT.

*AE OPTION CARDS WILL HAVE ONLY A NORMALLY OPEN, (N.O.), CONTACT AVAILABLE.

*BE OPTION CARDS WILL HAVE ONLY A NORMALLY CLOSED, (N.C.), CONTACT AVAILABLE.

ACROSS THE POINT TERMINAL BLOCK TERMINALS HAVING ACTIVE CONTACTS (130VAC MAX.)

*CE OPTION CARDS WILL HAVE BOTH A NORMALLY OPEN AND A NORMALLY CLOSED CONTACT AVAILABLE. > CONTACTS SHOW RELAYS IN THE DE-ENERGIZED IN NORMAL CONDITION, (FACTORY DEFAULT IS ENERGIZED).

FIF TRANSIENT SUPRESSION FOR RELAY CONTACTS IS REQUIRED INSTALL PANALARM MODEL 90ATB14

CONTACT RATINGS: 5 AMP

250VAC OR 28VDC RESISTIVE. 120VAC OR 28VDC LAMP LOAD. 500 mA @ 125VDC RESISTIVE LOAD ONLY. 500 mA @ 125 mA @ 125VDC LAMP LOAD ONLY.

P/N 090-0098-3-01 REV.3

SEE SEQUENCE CARD MODEL NUMBER (LOCATED ON CARD HANDLE) FOR OPTION CODE ORDERED




PANALARM 1725 WESTERN DRIVE, WES PHONE: 1-630-231-5900 1725 WESTERN DRIVE, WEST CHICAGO, IL., 60185, U.S.A. FAX: 1-630-231-4502


.; .x.	INCHES	ETERS = 1.0 = 0.4		INCH (MM)	THIRD ANGLE PROJECTION
REV	ECN NO.	BY	APPD	DATE	SCALE NONE © 1999
00	7097-69B	SK	CNL	11/04/99	DRWN BY S. KUNCA
01	11872	SK	MAL	6/15/01	APPD CNL
					DATE 11/04/99
					91450-MB01-1-01-01.dwg
					SHEET 1 OF 2


-A-

WIRING DIAGRAM, SERIES 90, JUMPER CONFIGURATIONS MODEL 91MB01

DWG. NO. 91450-MB01-1







OPTION CODE	INPUT STATUS	N.O. 4 CONTACT STATUS 3	N.C. 4 CONTACT STATUS 3	DESCRIPTION .
1CE	NORMAL	$\dashv\vdash$	<i>−</i> ਮ −	FOLLOWS CONTACT OR TEST PUSHBUTTON
I ICE	ALARM	→ ₩	ート	
	TEST	-} \−	│ ⊢	
3CE	OFF	$\dashv\vdash$	→ \—	ON WHENEVER LAMP IS ON
305	FF/SF/STDY	-}-		
	TEST	-}	$\dashv\vdash$	B 13 611
4CE	NORMAL	\dashv \vdash	-} ∤-	FOLLOWS CONTACT ONLY
400	ALARM	7	\dashv \vdash	
	TEST	$\dashv\vdash$	7	
5CE	OFF	$\dashv\vdash$	→ ⊁−	ON WHEN LAMP IS ON DUE TO ALARM
302	FF/SF/STDY	-1 -		
	TEST	\dashv	-}\-	INPUT .
	NORMAL	\dashv \vdash	→ \-	
6CE	ALARM	- 1 /-	\dashv \vdash	ON ONLY WHEN
	ACK	$\dashv\vdash$	-} \-	HORN IS ACTIVE
	TEST	→ \	$\dashv\vdash$	



PANALARM 1725 WESTERN DRIVE, WEST CHICAGO, IL., 60185, U.S.A. PHONE: 1-630-231-5900 FAX: 1-630-231-4502

.x	LERANCE UNLESS SF INCHES MILLIM X = .040 X.0 = X = .015 0.X = X = .005 0.XX = ANGLES ±0°30°	ETERS = 1.0 = 0.4 = 0.1		INCH (MM)	THIRD ANGLE PROJECTION
REV	ECN NO.	BY	APPD	DATE	SCALE NONE © 1999
01	SEE SHT 1				DRWN BY S. KUNCA
					APPD CNL
					DATE 11/04/99
					91450-MB01-1-01-02.dwg
					SHEET 2 OF 2

WIRING DIAGRAM, SERIES 90, JUMPER CONFIGURATIONS MODEL 91MB01

DWG. NO.

91450-MB01-1

-A-