

## ALARM MANAGEMENT PRODUCTS

# AN-6100C

## Annunciator

### For Power Generation, Transmission & Distribution, Petroleum, Petrochemical and Other Process Industries

#### Alarm Monitoring System

AMETEK's AN-6100C Annunciator has all the features you need for an alarm monitoring system. Simple to install, configure and operate and flexible to change, expand and grow to meet future requirements. The AN-6100C has all these qualities along with reliable operation for your most critical needs. The AN-6100C is maintenance free; once installed, you will never have to worry about it.

#### Compact Design

With a depth less than 4-1/2", it can be easily installed into control panels, system cabinets and consoles. It is an ideal fit for replacing older systems or for new installations. The high density design provides up to 44 alarms in just 80 square inches of panel space.

#### Flexible Configuration

Create any system size up to 10 rows by 20 columns of windows. Four window sizes are available in several colors. The large windows can easily be converted into smaller ones, providing instant expansion for the future.

#### High Reliability

Each AN-6100C Annunciator is equipped with low power, long life white LEDs. Each alarm point uses a pair of LEDs providing ample illumination in all light conditions. You never have to worry about changing a lamp or having it fail when you need it the most.

#### Multi-Function

All features and options are provided in a single model, making it easy to order or to change in the future. Our innovative software configuration tool is used to change any system parameter, such as: ISA alarm sequence, alarm grouping, input delays or relay operation.

#### Serial Communication

Alarm information is easily transmitted or received with the bi-directional serial Modbus communications. The RS-232/485 serial communications can act as a "Secondary" or "Main" providing control or monitoring of the alarm information.

#### Field Changeable

The window legends are printed on standard transparency film, making it easy to change legends at any time. Even options like serial Modbus can be added in the future through a factory supplied password.



### FEATURES AND BENEFITS

- 1 Compact design
- 2 Minimal depth behind panel
- 3 Bi-directional serial communications
- 4 LED illumination
- 5 Multi-function
- 6 Software configured
- 7 Laster printed legends
- 8 Removable terminal blocks

# SPECIFICATIONS

## INPUT

### FIELD CONTACTS

- Normally Open (N.O.) or Normally Closed (N.C.) input selection through DIP Switch
- Wet (voltage supplied) or dry (voltage free) contacts

### FIELD CONTACT VOLTAGE

- 5, 24, 48, 125 VDC, 120 VAC/DC
- 24 VDC open collector
- 24 VDC provided by annunciator power supply. Other voltage customer supplied.

### INPUT ISOLATION

- Each input is optically isolated
- Inputs share common return\* (\*120 VAC/125 VDC input option provides isolation input to input)

### INPUT RESPONSE

- 50 milliseconds (nominal)
- Adjustable to 2 seconds

## DISPLAY

### LED

- Dual White LED, 18 mA @ 24 VDC

### WINDOW SIZES

- Small: 0.98 x 1.14 inch (25 x 30 mm)
- Medium: 0.98 x 2.40 inch (25 x 60 mm)
- Large: 2.13 x 2.40 inch (55 x 60 mm)
- Extra Large: 2.13 x 4.96 inch (55 x 125 mm)

### WINDOW COLORS

- White, red, yellow, amber, green, blue

### LEGENDS

- Laser printed on transparency film

## ALARM SEQUENCE

### SEQUENCE SELECTIONS

- ISA-A, A4, A456, M, R12, F1A, F2M, FFAM2, F3A, R12C, F3C
- Dual color sequences
- Customized flash rates
- Up to 4 first out groups

## CONTROLS

- Integral test, acknowledge, silence and reset
- External push button inputs

## OUTPUTS

### AUXILIARY RELAY OPTION

- Individual relay per point
- Follows field contact or alarm sequence
- Energized or de-energized
- Form A or Form B (N.O. or N.C.)

### COMMON RELAYS

- Four relays selectable for:
  - Critical and non-critical: horn, reflash, common alarm
  - Ringback audible, watchdog
- Energized or de-energized
- Form A or Form B (N.O. or N.C.)

### RELAY RATINGS

- 30 VDC @ 2.0 amps
- 110 VDC @ 0.3 amps
- 120 VAC @ 0.5 amps

### AUDIBLE

- Internal 80 db audible device

## SERIAL MODBUS OPTION

- RS-232 OR RS-485
- Modbus RTU or ASCII
- Main or secondary mode
- Monitor mode (alarm information transmitted externally)
- Actuate mode (alarm information received externally)
- Pushbutton controls

## CONNECTIONS

### INPUT/OUTPUT TERMINALS

- Two-part removable screw type
- Maximum wire size: 12 AWG (2.5 mm)

### COMMUNICATION PORT

- Serial: 9 pin female D connector

## POWER REQUIREMENTS

### OPERATING RANGE

- 24 VDC +/-15%
- Burden: 7.5 VA per 8 inputs

### EXTERNAL POWER SUPPLY OPTIONS

- 88-264 VAC 50/60 Hz
- 72-144 VDC
- 36-72 VDC

## MECHANICAL

### DISPLAY MODULE (CELL)

- 2.83" H x 5.67" W (72 x 144 mm)
- 1, 2, 4, 8 windows per cell

### WEIGHT

- 0.85 lb. per cell (0.4 kg per cell)

## ENVIRONMENT

### OPERATING TEMPERATURE RANGE

- -4 to 122°F (-20 to 50°C)

### HUMIDITY

- 20-95% RH

### SURGE WITHSTAND

- ANSI C37.90.1

### ISOLATION

- 1950 VDC or 1400 VAC input to output/case/common, output to case/common

## CERTIFICATIONS

- CE, UL, ULC

### Annunciator Mounting Details

	Number of Cells Wide				
	1	2	3	4	5
Bezel Width	5.83 (148)	10.98 (279)	16.13 (410)	21.28 (541)	26.43 (671)
Cut-out Width	5.50 (140)	10.65 (270)	15.80 (401)	20.95 (532)	26.10 (663)
	Number of Cells High				
	1	2	3	4	5
Bezel Height	2.99 (76)	5.29 (134)	7.59 (193)	9.89 (251)	12.19 (310)
Cut-out Height	2.66 (68)	4.96 (126)	7.26 (184)	9.56 (243)	11.86 (301)

Allow 4.5" depth behind panel

### WORLD HEADQUARTERS

255 North Union Street  
Rochester, NY 14605  
Toll Free: +1.800.950.6686  
Tel: +585.263.7700  
Fax: +585.454.7805

### EUROPEAN HEADQUARTERS

UK  
+44.770.280.9377  
power.sales@ametek.com

### ASIA PACIFIC HEADQUARTERS

Singapore  
+65.6484.2388  
sales@ametekasia.com

### AMETEK INSTRUMENTS INDIA PVT. LTD.

Bengaluru  
+91.80.6782.3252  
power.sales@ametek.com

### WEBSITE

www.ametekpower.com

### EMAIL

pi.marketing@ametek.com



# AMETEK®

## POWER INSTRUMENTS

REV 06/2023