



DOOR LOCKING DEVICE  
T = 1/4-20 BLOTS  
OR  
H = "T" HANDLE

CABINET SIZE		"A" DIMENSION OVERALL	"B" DIMENSION WINDOW	"C" DIMENSION CUTOUT
MODULES ROWS HIGH	MODULES ROWS WIDE			
1	-	229 (9.00)	102 (4.00)	176 (6.94)
2	2	317 (12.47)	190 (7.47)	264 (10.41)
3	3	405 (15.94)	278 (10.94)	352 (13.88)
4	4	493 (19.41)	366 (14.41)	441 (17.34)
5	5	581 (22.88)	454 (17.88)	529 (20.81)
6	6	669 (26.34)	542 (21.34)	617 (24.28)
7	7	757 (29.81)	630 (24.81)	705 (27.75)
8	8	845 (33.28)	718 (28.28)	793 (31.21)
9	9	933 (36.75)	806 (31.75)	881 (34.69)
10	10	1021 (40.21)	895 (35.22)	969 (38.16)

MODEL NUMBER EXPLANATION:

90 CF\*  
SERIES 90  
TOTALLY ENCLOSED NON-VENTILATED CABINET

8 H = WITH "T" HANDLE  
T = WITH 1/4-20 BOLTS  
UNITS HIGH  
1 THROUGH 10  
UNITS WIDE  
1 THROUGH 10

7 VARIATION  
(BLANK FIELD INDICATES STANDARD NEMA 12, C.R.S. DOOR)  
N4 = NEMA 4, C.R.S. DOOR  
N4X = NEMA 4X, STAINLESS STEEL DOOR  
X = NEMA 12, STAINLESS STEEL DOOR

- NOTES:
- ALL DIMENSIONS ARE IN MILLIMETERS WITH CORRESPONDING INCH DIMENSIONS IN PARENTHESES.
  - DOOR FINISH IS CORROSION RESISTANT BAKED BLACK ENAMEL.
  - ALL FIELD WIRING IS ACCESSIBLE FROM REAR OF CABINET.
  - CABINET MOUNTS THRU A PANEL CUTOUT (DIM. C)
  - DOOR PANEL AND WINDOW ARE GASKETED.
  - MODULE ROWS HIGH & MODULE ROWS WIDE REFER TO THE MODULES NOT THE INDIVIDUAL WINDOWS. FOR FURTHER INFORMATION CONCERNING THE ANNUNCIATOR CABINET, REFER TO DRAWING 90100-CA-1.
  - ONLY CABINETS 5H X 7W AND SMALLER ARE AVAILABLE WITH N4 OR N4X OPTION.
  - N4 & N4X OPTION NOT AVAILABLE WITH "H" VERSION.

REV	ECN NO.	BY	APPD	DATE	MATERIAL:
00	9043	AK	RCV	07/17/84	FINISH:
01	8984-08	JJ	RCV	09/14/84	USED ON/REF. DWG
02	9185-08	JJ	RCV	07/08/85	90CF*
03	10881	SM	JT	01/13/92	90100-CA-1
04	10925	SM	CNL	05/12/93	90800-CF*-1
05	11695-01	AD	JT	10/17/95	90800-CA-1
06	11872	SK	MAJ	6/15/01	90DPA*

TOL. UNLESS SPECIFIED

INCHES  
.X = .015  
.XX = .010  
.XXX = .005

MILLIMETERS  
X.0 = 1.0  
0.X = 0.4  
0.XX = 0.1

ANGLES ±0° 30'

SCALE INCH (MM)  
NONE

**PANALARM** 1725 WESTERN DRIVE, WEST CHICAGO, IL., 60185, U.S.A.  
PHONE: 1-630-231-5900 FAX: 1-630-231-4502

DIMENSIONAL OUTLINE, SERIES 90,  
FLUSH MOUNT ANNUNCIATOR INSTALLED IN TOTALLY ENCLOSED  
NON-VENTILATED CABINET, (TENV), MODEL 90CFH\* OR 90CF\*

SHEET 1 OF 1      DWG. NO. 90115-CF\*-1      -B-