

REMOTE PUSHBUTTON WIRING



INTEGRAL PUSHBUTTON MODEL NO. 90PB31*

COMMON AUXILIARY RELAY WIRING

FOR CUSTOMER USE IF REQUIRED





RELAY CONTACTS RATED 4 AMPS AT 250VAC OR 5 AMPS AT 28VDC OR 120VAC AND 0.5 AMP AT 125VDC RESISTIVE LOAD.

11872

NT2-24D AUDIBLE DEVICE WIRING

DIAGRAM SHOWS NOVATONE HORN WITH P1 TERMINAL BLOCK ON P.C. BOARD ATTACHED TO HORN (REF. DWG. 57100–48) FOR EARLIER VERSIONS WITH PIGTAIL LEADS, CONNECT BLACK TO OV, RED TO +24 AND BLUE TO FLASHER TERMINAL (REF. DWG. 57100–44).





OPERATIONAL SEQUENCE "AM"						
INPUT STATUS	VISUAL	AUDIBLE				
ALARM OR TEST	FLASHING	ON				
ACKNOWLEDGE	STEADY-ON	OFF				
RETURN TO NORMAL	STEADY-ON	OFF				
RESET	OFF	OFF				

NOTES:

- IF A NEW ALARM OCCURS WHILE TESTING, POINT WILL INDICATE ALARM CONDITION (RE-ALARM) AFTER ACKNOWLEDGE PUSHBUTTON IS OPERATED.
- POINT WILL INDICATE ALARM WHEN TEST PUSHBUTTON IS OPERATED IF THE VISUAL INDICATOR IS OFF OR STEADY—ON.

						<u> </u>	
REV	ECN NO.	BY	APPD	DATE	MATERIAL:		TOL. UNLESS SPECIFIED
00	6781-04	DMW	ARF	02/18/81	FINISH:		INCHES
01	6783-38	ww	RAS	10/02/81	USED ON/REF. DWG	DESCRIPTION	.X = .015 .XX = .010
02	8700-42	AK	JWK	05/19/83	91AF*	DRAWING LIST	.XXX = .005
03	9090-13	TA	AHD	10/02/84	92AF*	DRAWING LIST	MILLIMETERS X.0 = 1.0
04	9143-03	IR	PG	04/19/88	93*	DRAWING LIST	0.X = 0.4 0.XX = 0.1
05	7099-74	SK	PG	06/06/89			ANGLES ±0.30'
06	10761-01	SM	PG	06/18/92			SCALE INCH

90450-AF3-1-07-01.dwg

lo 1981

DWN. BY DMW/SM
APPD/DATE ARF 02/18/81
THIRD ANGLE PROJECTION

PANALARM 1725 WESTERN DRIVE, WEST CHICAGO, IL., 60185, U.S.A. PHONE: 1-630-231-5900 FAX: 1-630-231-4502

CUSTOMER WIRING DIAGRAM AND SEQUENCE 'AM' INFORMATION FOR SERIES 90

SHEET 1 OF 1

DWG. NO.

90450-AF3-1

-B-