

TR-100+ Digital Fault Recorder

FOR GENERATION, TRANSMISSION, AND DISTRIBUTION POWER SYSTEM MONITORING



DIGITAL FAULT RECORDER

The AMETEK TR-100+ is a fully-featured Digital Fault Recorder with the capability to capture and analyze short transient events, longer term disturbances and trend input quantities such as RMS. frequency, harmonics. power and power factor. The high speed, high resolution recording and flexible triggering modes make the TR-100+ ideal for monitoring protection operations, swing events, power quality, phasors, sequence of events, asset condition and load profiles. The TR-100+ can be scaled to almost any application to obtain the best cost for



performance, with selectable architecture from 8-160 analog inputs and a complete suite of software applications. The system can automatically retrieve events and perform an expert analysis so you have the answers fast, saving time and money. Optimize your power system to improve reliability, shorten your fault clearance times and verify correct operation of your switchgear and other protection equipment. The TR-100+ is ideally suited for your generation, transmission and distribution power system monitoring.

The TR-100+ can be matched to any application with models available for:

TR-108+: 8 Analog/16 Digital Inputs TR-116+: 16 Analog/32 Digital Inputs TR-124+: 24 Analog/48 Digital Inputs TR-132+: 32 Analog/64 Digital Inputs Systems up to 160 Analog/320 Digital Inputs

For portable testing and verification, we have the DL-8000+ monitor that includes the same features of the TR-100+ in 8 or 16 analog inputs, with easy access jacks for quick connections.

FEATURES AND BENEFITS

- Transient fault recorder—post fault analysis to verify protection and circuit breaker opera tions, fault clearance times and distance to fault
- Disturbance recorder—extended recording and logging for slow disturbances and steady state RMS values, harmonics and optional real power and power factor
- Power quality monitor—voltage and frequency profiles, voltage dips and surges, loss of supply, and harmonic content
- Fault locator—calculates distance to fault based on configurable line model
- Real time monitor—view analog, digital inputs and computed values in near real time
- On-line switchgear monitor—used to identify condition based service time for switchgear by accumulating contact wear



Experience the Power™

SPECIFICATIONS

INPUTS

Number of Channels

- 8, 16, 24, or 32 analog
- 16, 32, 48, or 64 digital (larger systems available)

Voltage Inputs

 57 to120 V RMS nominal, 212 V RMS full scale

Current Inputs

• 1 A or 5 A RMS nominal (thru external current shunts/CICT's)

Frequency Response

 DC to 3,000 Hz, (+0dB, -3dB) or 1/4 sample rate

Accuracy

• Better than 0.2% full scale

Digital Inputs

 24-250 VDC normally open or normally closed wetted contact

RECORDING-FAULT

Resolution

16 bit A/D converter

Sample Rate

- 64, 128, and 256 samples/cycle
- **Pre-fault Time**
- 2 to 300 cycles

Post-fault Time

 8 cycles to 30 seconds. Fault length can optionally extend for as long as a trigger con dition exists to the maximum record length

Safety Window

Recording time after end of triggers: 0 to 16 cycles

Maximum Record Length

• 30 seconds

Total Recording Time

- RAM: 64 MB (approx. 80 seconds at 64 sam ples/cycle with 32 channels) used as a buffer
- Minimum 40 Gb hard drive: Up to a maxi mum of 1024 records

Multi-Recorder Synchronization

• Channels between cross triggered recorders are timed to within 1 sample

RECORDING - DISTURBANCE

Sample Rate

- 100/120 samples/seconds
- Pre-fault Time
- 2 to 600 seconds

Post-fault Time

• 4 to 300 sec. fault length can optionally ex tend for as long as a trigger condition exists to the maximum record length

Safety Window

Recording time after end of triggers: 2 to 120 seconds

Maximum Record Length

10 to 1200 seconds

RECORDING-LOGGING

- Sample Rate
- 1 or 0.1 samples/minute

Recording Time

• 16 weeks - circular buffer

Recorded Values

 Maximum, minimum and average RMS volt age, current, frequency, real power (optional), and power factor (optional)

Harmonics

 Average amplitude up to 63rd every 10 minutes (EN61000-4-7)

TRIGGERING

Analog

 Over and under limit with hysteresis, rate of change per input, zero and negative sequence, over/under/R-o-C of positive sequence, THD and over/under/R-o-C of frequency

Digital

Alarm and return to normal, edge or level sensitive

SYSTEM TIMING

Time Synchronization

 Internal clock, synched to the 50/60 Hz line or optional IRIG-B

COMMUNICATIONS

Serial Ports

- Up to 3 x RS232 type, local and remote communications
- DNP3

Modem

 Hayes compatible type internal or external (57.6 kbaud optional)

Phone Line Sharing

• External unit to share a single phone line with a station phone (optional)

Network

- 10Base2 (50 ohm coax and BNC),
- 10baseT (UTP), ST Fiber (optional)
- Network protocol: TCP/IP

STATUS RELAYS

Relay Function

 Power OK; Armed/ready; Attention; System triggered

Contact Rating

• 400 VDC/280 VAC, 1 A maximum

POWER SUPPLY

Input Voltage Options

88 to 300 VDC, 85 to 264 VAC, 24 or 48 VDC optional

Power Requirement

• 30 VA (16 channel) 45 VA (32 channel)

ENVIRONMENTAL/ ELECTRICAL STANDARDS

Operating Temperature • 14° to 131°F (-10° to 55°C)

Relative Humidity

• 0 to 95% non condensing

IEEE/IEC

Asia Pacific Headquarters

Singapore 486164

Tel: +65 6484.2388

Fax: +65 6481.6588

sales@ametekasia.com

#04-01

No. 43 Changi South Avenue 2

HANALARIV

ISO 9001 Certified

• Isolation, impulse voltage, RFI and ESD CE Mark

AMETEK Instruments India Pvt. Ltd.

Plot 148 FPIP Phase II

Tel: +91 80.67823252

Fax: +91 80.67823232

Whitefield, Bengaluru 560 066

powersales.india@ametek.com

1st Floor, Prestige Featherlite Tech Park

MECHANICAL DETAILS

- TR-108+, TR-116+
- 19 in. wide rack, 30 lbs. (13.7 kg) 5U high (8.73 in.)

TR-124+, TR-132+

• 19 in. wide rack, 60 lbs. (27.4 kg) 7U high (12.23 in.)



European Headquarters

Tel: +44 (0) 28.9260.4100

Fax: +44 (0) 28.9260.4141

sales@ametekuk.com

Ballinderry Road

Unit 15, Lisburn Enterprise Centre

Lisburn, Co Antrim, UK BT282BP

PAC

ROCHESTER

0M712PDF (210073)

For Customer Support

AMETEK Power Instruments 255 North Union Street Rochester, NY 14605 Tel: +1 585.263.7700 Fax: +1 585.454.7805 power.sales@ametek.com

SCIENTIFIC COLUMBUS

U.S.A. Headquarters AMETEK Power Instruments 50 Fordham Road

Wilmington, MA 01887

Tel: +1 978.988.4903

Fax: +1 978.988.4990

www.ametekpower.com

power.sales@ametek.com

Guiton

©2012, by AMETEK, Inc. All rights reserved.