

Ci20 Electric Revenue Meter

FOR ADVANCED METER APPLICATIONS



REVENUE METER

AMETEK's Ci20 Revenue Meter watches over your energy investment in many ways. It has high accuracy measurements, site diagnostics and dependable communication options to ensure maximum reliability. Your installation investment is reduced with our innovative software wizard that provides quick set-up and configuration. Inventory and ordering is simplified with field upgradeable options using soft switches and plug in boards.

High Accuracy Measurements

The AMETEK Ci20 provides an impressive 0.15% accuracy on watt-hours with additional improvements from Transformer Correction and TLC measurements. Per phase and system measurements are available including Four Quadrant and Bidirectional. The AMETEK Ci20 comes with 4 channels of Load Profile, upgradeable to 12 channels

Multiple Communication Choices

The Ci20 can be equipped with dual serial outputs, or single serial output with Modem or Ethernet ports. A built-in Web server provides secure access of measurements using a standard Web browser. Support is provided for DNP, Modbus, ANSI tables and MV90.

Quick Installation and Upgrades

The Windows based JEMWARE software configuration wizard reduces configuration time and minimizes errors with the step by step process. Options can be easily added via soft switch or plug in option boards. A universal form option provides access to multiple 3 phase circuit connections in one meter configuration. Order one standard configuration and upgrade it easily at your site to support any installation needs.

Graphic Display

The Ci20 has a large easy to read graphic LCD display for displaying any metered value, health status, alarms and general operation. The secure menu driven display provides access to your meter configurations for quick changes.

Site Diagnostics

The AMETEK Ci20 will determine whether the meter is properly connected through the Installation Verification mode, which displays the per



phase measurements and phase vectors on the graphic LCD display. Once installed, the Ci20 continuously checks the operating conditions against pre-set thresholds with alarms triggered for local or remote notification. The meter can phone any number upon an alarm including a complete power loss, providing quick notification of outages.

Continuous Power

The Ci20 will operate off any phase, preventing a loss of recording when one or two phases are dropped. Combined with the site monitoring feature, notification of this event can be provided via automatic modem call, alarm contact and meter reads.

Digital I/O

The Ci20 has 6 channels that can be selected as configurable inputs or KYZ outputs. The inputs can also be wetted through our internal isolated supply.

Power Quality

The Ci20 can monitor and report your site's power quality conditions with sag and swell recording, THD, power factor, imbalance and frequency measurements.

Totalization

With up to 6 configurable inputs, you can totalize a variety of measurements providing a consolidated output.

AMETEK[®]
POWER INSTRUMENTS

EXPERIENCE THE
POWER[™]

SPECIFICATIONS

METER FORMS

Meter Forms: 5, 6, 8, 9, 26, 35S, Universal

INPUTS

Voltage

- 55-530 VAC auto-ranging
- Burden*: 0.5 VA @ 530V

*Does not include auxiliary power requirements.

Current

- 10 Amps: ANSI Class 20
- Burden: 0.5 VA maximum
- Overload: 1.5x rated class current continuous, 20x rated class current for 0.50 sec
- Frequency range: 45-55 Hz, 55-65 Hz

AUXILIARY POWER

55 – 530 VAC

- Derived from from A,B or C phase voltage input
- Auxiliary Power Burden
- 15 VA maximum

ACCURACY

Watt-hour

- 0.15% reading

Clock

- Synchronized to line or +3 minutes per month maximum error

MEASUREMENT PLUS

Additional 15 or 35 Measurements (Base Meter Includes 15)

PER PHASE MEASUREMENT

Energy Per Phase Quantities

- Watt-hour, VAR-hour, VA-hour Am-hour, Amp²-hour, Volt²-hour, Q-hour

Instantaneous Per Phase Quantities

- Watts, VARs, Quadrant Vars, VA, Q, PF, Volts, Amps, Neutral Current, Volts², Amps²

TIME OF USE

9 Rates, 20 Year Calendar

SITE MONITORING

Set Alarms for Under/Over Voltage and Current, Power Factor. Trigger an Alarm Contact or Phone any Number

DEMAND PREDICTION

Determines in Advance When Demand will Exceed Pre-set Threshold

LOAD PROFILE +

12 Channels of Storage (61 Days @ 15 Minute Intervals)

ALARM THRESHOLDS

Set Alarms for any Energy or Instantaneous Measurement

Trigger an Alarm Contact or Phone any Number

MEASUREMENTS

Energy PolyPhase Quantities

- Watt-hour, VAR-hour, VA-hour, Am-hour, Amp²-hour, Volt²-hour, Q-hour

Instantaneous Quantities

- System: Watts, VARs, Quadrant Vars, VA, Q, PF, Volts, Amps, Amps², Average Volts,

4 Quadrant Bi-Directional

REGISTERS

15 Normal or Alternate Using Any Measurements Above

Demand Registers

- Fixed or sliding window
- Interval length: 1-60

LOAD PROFILE

4 Channels of Storage (Standard)

Programmable Interval

- 1-60 minutes

64 Days Storage Using Four Channels at 15-minute Intervals

MECHANICAL

Case Styles

- S base and A Base

Size and Weight

- S base: 4.5 pounds
- A-base: 6.5 pounds

COMMUNICATIONS

Optical Port (Standard)

- Type 2 – 19,200 Baud
- JEM Binary

ENVIRONMENT

Operating Temperature

- -22° to 185°F (-30° to 85°C)

Storage Temperature

- -40° to 185°F (-40° to 85°C)

Humidity

- 5 to 95% relative humidity, non-condensing

Surge Withstand (SWC)

- ANSI Standard C62.41

Fast Transient

- 4kV inputs, 2kV I/O (IEC 61000-4-4)

EMC

- FCC Part 15, Class B, FCC Part 68

STANDARDS

Agency Standards and Certifications:

- ANSI Standard C12.1-2001
- ANSI Standard C12.18-1996
- ANSI Standard C12.19-1997
- ANSI Standard C12.20-2002
- Measurement Canada

METER OPTIONS AND UPGRADES

COMMUNICATIONS

One Comm option board per meter

Serial Port Board

- Single or dual serial port
- Field selectable for RS-232 or RS-485
- User configurable: 300 to 38400 baud

Internal Modem Board

- 2,400 baud
- With optional serial port (RS-232/485)
- With optional phone home on power fail

Ethernet Board

- 10 baseT, unshielded twisted pair
- Up to 4 simultaneous connections
- With optional serial port (RS-232/485)

Communication Protocols

- Modbus ASCII, RTU, TCP/IP
- DNP 3.0
- ANSI Tables C12.19

TOTALIZATION

Up to 6 Contact Inputs (from Digital Input/Output Board)

Up to 12 Totalization Measurements Displayed and Recorded

Web Browser

- View power measurements and site conditions from a standard Web browser.

EXTERNAL AUX POWER

Can be powered externally with 55-530VAC or 90-250VDC

INPUT/OUTPUT BOARD

Six Channels Individually Selectable for a Form-A Contact Input or KYZ Solid-state Output.

Contact Inputs (wet or dry)

- User-configurable for: pulse counter, interval synchronization pulse, TOU rate override, status input, totalization
- Customer wetted contact – maximum voltage 40 VDC
- Customer dry contact – optional internally powered 12 VDC

Solid-state Outputs

- User-configurable for: any consumption quantity, energy pulse (KYZ), site monitor alarm, threshold alarm, demand sync, voltage sag/swell alarm, system error alarm
- Maximum open-circuit voltage: 200 VDC or Peak AC
- Maximum switching current: 50 mA

POWER QUALITY

Configurable Thresholds for Voltage Sags and Swells per Phase

Records Start and Duration in Cycles

Records Min/Max/Avg Voltage and Current per Phase, Avg Power Factor

Stores Up to 100 Events

Maximum Event Length of 600 Cycle



WORLD HEADQUARTERS

255 North Union Street
Rochester, NY 14605
Toll Free: +1.800.950.6686
Tel: +585.263.7700
Fax: +585.454.7805

EUROPEAN HEADQUARTERS

UK
+44.770.280.9377
power.sales@ametek.com

ASIA PACIFIC HEADQUARTERS

Singapore
+65.6484.2388
sales@ametekasia.com

AMETEK INSTRUMENTS INDIA PVT. LTD.

Bengaluru
+91.80.6782.3252
power.sales@ametek.com

WEBSITE

www.ametekpower.com

EMAIL

pi.marketing@ametek.com

